

Jaký CD changer k jakému autorádiu Grundig

Typ changeru	Počet CD	Typ autorádia
MCD10 (+ interface MCD-A1)	10	WKC3880RDS, WKC4870RDS, WKC4871RDS, WKC4872RDS, WKC5500RDS
MCD20 (+ interface MCD-A1)	10	
MCD30 (+ interface MCD-A2)	6	
MCD30	6	Všetchna autorádia Grundig s konektorem MINI-ISO, např.
MCD36	6	Škoda : MS201(A), MS401(A), MS411A
MCD40	10	Seat : 3301
MCD46 (CD text)	6	Smart : Smart Radio
MCD50 (CD text)	10	Fiat : AD182H(2,4), AD183M, AD185H (pouze 6 disků!)
3BO 035 111B (VW)	10	Propojovací kabel (5 m): obj. číslo 197721960000
CX-CV1620L2 (Matsushita)	10	Škoda : MS502(A), Symphony
		Audi : Concert, Chorus
		Seat: Aura(V3), Brisa (V3), High